

Mixing Silicone Rubber



Measure out the amount of rubber you want to mix. Make sure you are going to have enough to completely fill your mold box.



Add (1) part of catalyst to every (10) parts of base.



Pour the catalyst into the base.



Mix thoroughly until an even color is achieved. Be sure to scrape the sides and bottom.



This is what it should look like when completely mixed.